




## EXTREME GEARED REEL OPERATING INSTRUCTIONS




## <section-header><text>





## IN USE - REELING IN



Push the lever forward to dis-engage drag. This also lets the pawl engage to stop reeling out.